

Passa muros em PVC


PVC Tank adaptor

Traversée de paroi en PVC

Manguito tanque PVC



01 10 1312 000



d	D	d1	G	L	L1	Z	I	S	Gr	Quant	Nº Código
16	20	14,5	" 1/2	16	33	13	61	25	20	B 150	01 10 1312 006
20	25	20	" 3/4	19	42	17	74	32	42	B 70	01 10 1312 010
25	32	25	1"	22	45	19	82	40	66	B 40	01 10 1312 014
32	40	32	1 " 1/4	26	49	20	92	50	110	C 100	01 10 1312 018
40	50	37	1 " 1/2	31	49	23	98	60	188	C 60	01 10 1312 020
40	50	40	1 " 3/4	31	49	23	98	60	190	C 60	01 10 1312 022
50	63	50	2 "	38	52	25	111	69	240	C 40	01 10 1312 026
63	75	63	2"1/2	43,5	52	25	116,5	78	290	C 30	01 10 1312 028
75	90	75	3"	51	58	28	130	92	333	C 24	01 10 1312 030