

06.06 Válvulas roscadas

PVC-U Roscar 7 referências

| G       | A   | B   | E   | F   | I   | L  | L1 | M  | Peso (g) | Emb. | REF.        | 3D |
|---------|-----|-----|-----|-----|-----|----|----|----|----------|------|-------------|----|
| " 3/4   | 65  | 65  | 92  | 54  | 111 | 28 | 20 | 45 | 280      | C 40 | 01601077034 | -  |
| 1 "     | 65  | 65  | 92  | 54  | 111 | 28 | 20 | 45 | 280      | C 40 | 01601077100 | -  |
| 1 " 1/4 | 90  | 93  | 131 | 74  | 148 | 36 | 23 | 62 | 644      | C 16 | 01601077114 | -  |
| 1 " 1/2 | 90  | 93  | 131 | 74  | 148 | 36 | 23 | 62 | 635      | C 16 | 01601077150 | -  |
| 2 "     | 111 | 111 | 155 | 86  | 168 | 44 | 27 | 62 | 1100     | C 10 | 01601077200 | -  |
| 2 " 1/2 | 168 | 184 | 221 | 140 | 238 | 47 | 43 | 84 | 3130     | C 3  | 01601077250 | -  |
| 3 "     | 168 | 184 | 221 | 140 | 242 | 55 | 51 | 84 | 3200     | C 3  | 01601077300 | -  |

Legenda das cotas: G = Rosca (in), I = Profundidade de encaixe (mm), L = Comprimento (mm), L1 = Comprimento (2) (mm)

PDF: /images/pdf/capitulo6/06-06.pdf